

index

Page numbers shown in *italic* indicate figures.

Numbers & Symbols

12T gear, 265
24T gear, 265
36T gear, 265
/ (division operator), 332
% (modulo operator), 332
* (multiplication operator), 332

A

accelerating a motor, 220
Action blocks, 27
Advanced blocks, 27
Advanced mode, Math block, 229
Ambient Light Intensity mode, 75, 85
And mode, Logic Operations block, 233
angled beams, 107–108
 extending gears along, 130
ANTY robot, 171
 avoiding obstacles, 190–191
 building, 173–189
 finding food, 191
 parts list, 173
 placing motors in opposite positions, 190
 sensing color in environment, 191–193
 walking mechanism, 172
Available Bricks tab, 354
axles, 105
 determining length of, 9
 extending using connector blocks, 111
 perpendicular, 132
 preventing from falling out, 110
 preventing from twisting, 135
 using with cross holes, 110
 using with sensors, 119

B

backlash from gears, 128
backward, driving, 36, 38

ball magazine, 119
ball shooter, 119
batteries
 EV3 rechargeable, 4
 for remote control, 4
 replacing, 21
beacon. See remote control
Beacon Heading mode, 93–94
 Beacon Proximity and, 219
 measurements for, 303
Beacon Proximity mode, 93
beams, 105
 adding attachment points to Large Motor, 135–136
 angled, 107–108
 bracing gears with, 134
 connecting at right angle, 111, 113
 connecting parallel, 111, 112
 connecting to Large Motor, 118
 determining length of, 9
 extending, 106
 measuring, 106
 reinforcing structures, 107
 securing parallel, 111
 using with sensors, 119
bevel gears, 128, 130–131
blocks (programming), 35, 227.
 See also individual blocks
 arranging, 28
 deleting, 27
 duplicating, 31
 EV3 brick buttons and, 97–98
 help for, 31–32
 modes and settings for, 35, 37
 multitasking
 multiple Start blocks, 56
 resource conflicts, 57
 splitting Sequence Wire, 56
My Blocks. See My Blocks
negative power value, 38
On Brick programs. See On Brick programs
placing in program, 26
running selected, 29

troubleshooting errors, 351–352
types of, 27
viewing currently running, 353
Bluetooth
 connecting with, 357–358
 dongles, 357
 downloading programs, 356
 Settings tab, 21
 vs. Wi-Fi, 358
bonus models, 32
bracing gears with beams, 134
Brake at End setting, 38, 164
brick. See EV3 brick
Brick Apps tab, 21
Brick Buttons block, 217
Brick Buttons sensor, 97–98
Brick Status Light block, 44, 218, 353
bumper using Touch Sensor, 62–65
bushes, 105
 attaching too tightly, 122
 preventing axles from falling out, 110
buttons, EV3 brick, 20–21
 programming with, 97–98

C

cables, 20
cam, 114
Change mode, 67, 68, 73
Clear Screen setting, Display block, 42
closing programs, 29
Color mode, 75, 77
color reference chart, 77
Color Sensor, 62, 75
 Ambient Light Intensity mode, 75, 85
 attaching to EXPLOR3R, 75–76
 Color mode, 75, 77
 color reference chart, 77
 detecting handshake, 345
 following line, 79–80
 following line, smoothly, 83–84
 Reflected Light Intensity mode, 75, 81
 following line smoothly, 83–84
 threshold value, 82

- Color Sensor, *continued*
 - sensing color in environment
 - absence of color, 191–192
 - reacting to with ANTY, 192–193
 - staying inside colored line, 77–78
 - test track for, 77
 - Color Sensor block, 217
 - Color setting, Display block, 43
 - Comment block, 352
 - comments
 - tool for, 30
 - usefulness for troubleshooting, 352
 - Compare block, 232, 333
 - Compare mode, 73
 - Change mode vs., 67
 - Sensor blocks, 218
 - Touch Sensor, 219
 - compilation errors
 - missing My Block, 351
 - missing variable definition, 352
 - programming block errors, 351–352
 - compound gear ratio, 126
 - connections
 - Bluetooth, 357–358
 - troubleshooting, 354
 - connector blocks, 105
 - connecting beams at right angle, 111, 113
 - connecting parallel beams, 111
 - extending axles, 111
 - Constant block, 245
 - Variable block vs., 247
 - Content Editor, 32
 - Context Help, 32
 - copying programming blocks, 31
 - Count value, 249
 - cross hole, 110, 118
 - Current Power mode, 99, 100
 - curved turns, 40
- D**
- Data Operations blocks, 27, 227
 - Compare block, 232, 333
 - Logic Operations block, 233
 - modes for, 233
 - Not mode, 234
 - Math block. *See* Math block
 - Random block, 231
 - Range block, 234
 - Round block, 235
 - Text block, 235
 - data wires, 210–211
 - blocks inside Switch blocks, 222–223
 - deleting, 212
 - displaying value on the EV3 screen, 216
 - Logic, 214
 - Logic array, 215
 - Loop block and, 220–221
 - Math block and, 230
 - Numeric, 214
 - Numeric array, 215
 - placement in programs, 212
 - repeating blocks with, 213
 - seeing values from, 211
 - Switch block and, 221
 - Text, 214
 - type conversion, 215–216
 - using multiple, 212
 - using with My Blocks, 236
 - value range for, 219–220
 - Wait block and, 220
 - decompiling programs, 355
 - decorating robots, 119
 - decreasing speed, 123–124, 126–127
 - Degrees mode, 37
 - deleting data wires, 212
 - Demo* program, 22
 - Disconnect button, 354
 - Display block, 42
 - Clear Screen setting, 42
 - Color setting, 43
 - Display field, 42
 - position on screen, 43
 - Radius setting, 43
 - Shapes mode, 42
 - signaling progress using, 353
 - sub modes, 42–43
 - Text mode, 43
 - Wired setting, 216
 - division operator (/), 332
 - double-bevel gears, 128, 130–131
 - Download and Run button, 25
 - downloading
 - color reference chart, 77
 - EV3 programming software, 6–7
 - example programs, xxii
 - LEGO unit grid, 108
 - line-following tracks, 81
 - driving
 - acceleration, 39
 - backward, 36, 38
 - Duration setting, Sound block, 41, 224
- E**
- equality, checking, 232
 - equal to comparisons, 232
 - Equation setting, 229
 - EV3 brick, 3, 4. *See also* On Brick programs
 - batteries for, 4
 - buttons on, 20–21
 - programming with, 97–98
 - downloading programs to, 25, 28
 - using Bluetooth, 356
 - using Wi-Fi, 358
 - finding programs on, 30
 - memory management, 356
 - microSD card, 356
 - restarting, 355
 - running programs, 22
 - status light on, 21, 44
 - troubleshooting. *See* troubleshooting:
 - EV3 brick
 - turning on/off, 21
 - updating firmware, 355
 - EV3 programming software. *See*
 - also* blocks (programming);
 - programs; projects
 - Comment tool, 30
 - Content Editor, 32
 - controlling robot, 6
 - downloading, 6–7
 - downloading programs to the EV3, 25, 28
 - Hardware Page, 28
 - help for blocks, 31–32
 - installing, 7
 - launching, 25
 - Pan tool, 30
 - placing blocks in, 26
 - Programming Canvas, 27
 - Programming Palette, 27
 - projects vs. programs, 29
 - running programs manually, 28
 - running selected blocks, 29
 - Select tool, 30
 - Start block, 27
 - toolbar in, 30

- updating, 7
- Zoom tool, 30
- EV3 rechargeable battery, 4
- EV3RSTORM robot, 32
- EXPLOR3R robot, 9, 9
 - attaching Color Sensor, 75–76
 - avoiding obstacles, 67, 90–91
 - building, 10–18
 - connecting cables, 19
 - creating bumper using Touch Sensor, 62–65
 - following line smoothly, 83–84
 - following line using Color Sensor, 79
 - material list for, 10
 - regulated vs. unregulated speed, 101
 - test track for, 77
 - using multiple sensors, 90–91
- external devices, 20

F

- File Navigation tab, 21, 30
- firmware, updating, 25, 355
- Flat View vs. Tabbed View, 72
- flexible structures, 114–115
- Flow blocks, 27
- Formula EV3 Race Car robot, 141
 - building, 142–162
 - moving autonomously, avoiding obstacles, 168
 - parts list, 142
 - remote control program for, 166–167
 - steering, 163
 - centering, 164–165
 - left and right, 164
 - resetting, 163
 - testing, 166
- frames, 105, 106
- friction from gears, 128
- friction pins, 9–10, 105

G

- gears, 105
 - 12T gear, 265
 - 24T gear, 265
 - 36T gear, 265
 - bevel, 128, 130
 - bracing with beams, 134
 - calculating gear ratio, 123

- calculating output speed, 123
- compound gear ratio, 126
- connecting to motors, 136
- double-bevel, 128, 130
- extending along angled beam, 130
- friction and backlash, 128
- half units and, 129
- improper combinations of, 130
- included in set, 128
- increasing and decreasing speed, 123–124
- knob wheel, 128, 133
- perpendicular axles, 132
- perpendicular connections, 130–131
- preventing axles from twisting, 135
- radius of, 129
- ratio calculator, 129
- reversing rotation direction, 135
- spur gear, 128
- teeth on, 122
- torque, 124–125
 - decreasing, 125
 - increasing, 125, 126–127
- trains of, 121, 125–126
- unit grid and, 129
- uses for, 121
- worm gear, 128, 133–134
- grabber mechanism for SNATCH3R, 263–265
- greater than comparisons, 232

H

- half units, 114
 - gears and, 129
- handshake, detecting, 345
- Hardware Page, 28, 66, 354
- help for programming blocks, 31–32
- H-frame, 106
- hinges using nonfriction pins, 114

I

- idler gear, 126
- incrementing variables, 249
- infrared remote control. *See* remote control
- Infrared Sensor, 62
 - avoiding obstacles with, 90–91, 168
 - Beacon Heading mode, 93–94
 - Beacon Proximity mode, 93
 - capabilities of, 89

- combining sensor modes, 95
- Proximity mode, 89
 - avoiding obstacles, 90–91
 - combining with other sensors, 90–91
- Remote mode, 92
 - using remote control with, 92
- Infrared Sensor block, 217
- input gear, 126
- input ports, 20
- installing EV3 programming software, 7
- IR Control app, 22
- IR remote control. *See* remote control

K

- knob wheel gear, 128, 133

L

- Large Motor
 - adding attachment points, 135–136
 - calculating rotational speed, 100
 - connecting beams to, 118
 - connecting gears to, 136
 - connecting two using frame, 115
 - connecting wheels to, 115, 117
 - geometry of, 116
 - maximum torque, 125
 - regulated speed and power consumption, 101
 - rotational speed, 99
- Large Motor block, 46
- LAVA R3X robot, 311–312
 - avoiding obstacles, 344
 - building
 - head and arms, 335–343
 - legs, 312–329
 - head and arms control, 344
 - parts list, 312
 - resetting legs, 344
 - responding to triggered sensor, 345
 - walking
 - keeping legs in sync, 332–333
 - reset procedure, 330
 - returning motor to position, 330–331
 - test program, 334
 - turning left, 334
 - until sensor is triggered, 344–345

- LEGO MINDSTORMS EV3
 - Education Core set, 3
- LEGO MINDSTORMS EV3
 - Home Edition, 3
- LEGO units, 106
 - half units, 114
 - using grid, 108–109
- length of beams and axles, 9
- less than comparisons, 232
- lifting mechanism for SNATCH3R, 265
- Logic array data wire, 215
- Logic data wire, 214
 - using with Switch block, 221
- Logic mode, ending Loop block using, 220–221
- Logic Operations block, 233, 345
 - modes for, 233
 - Not mode, 234
- Logic variables, 246
- Loop block, 50
 - breaking out of
 - caveats, 224
 - from inside, 223
 - from outside, 223–224
 - Compare mode, 73
 - data wires and, 213, 220–221
 - ending using Logic mode, 220–221
 - Loop Index, 220
 - modes for, 50
 - naming, 51
 - nesting, 51–52
 - resizing, 51
 - sensors and, 68–69
 - Switch block in, 72
 - using with Color Sensor, 77
- Loop Interrupt block, 223

M

- Math block, 228
 - Advanced mode, 229
 - division operator, 332
 - modulo operator, 332
 - multiplication operator, 332
- measurements, using in calculations, 228
- Measure mode, 73
 - Sensor blocks, 217
 - Timer block, 235
- Medium Motor
 - calculating rotational speed, 100
 - connecting gears to, 136

- geometry of, 118
 - Rotation Sensor and, 163
 - torque from, 125
- Medium Motor block, 46
- Memory Browser, 354
- microSD card
 - adding memory, 20
 - folder for, 30
 - using in the EV3, 356
- mission pad, 5–6
- modes, programming block, 37
- modules, 106
- modulo operator (%), 332
- monster teeth, 119
- More Robots tab, 32
- Motor Control app, 22
- Motor Rotation block, 218
- motors
 - detecting stalled, 101
 - the EV3 and, 3
 - Large Motor. See Large Motor
 - Medium Motor. See Medium Motor
 - Move Steering block. See Move Steering block
 - Move Tank block, 46
 - moving at different speeds, 46
 - output ports, 20
 - Ports setting, 37
 - position
 - resetting, 99
 - Rotation Sensor and, 98
 - regulated vs. unregulated speed, 101
 - rotational speed, 100
 - Rotation Sensor, 62
 - as starting point for building, 115
- Move Steering block, 35
 - acceleration, 39
 - accurate turns, 39
 - Brake at End option, 38
 - modes for, 37
 - On/Off modes, 45, 332
 - Power setting, 37
 - Steering setting, 37
 - using, 35–36
- Move Tank block, 46
- multiplication operator (*), 332
- multitasking
 - multiple Start blocks, 56
 - resource conflicts, 57
 - splitting Sequence Wire, 56

- M unit, 106, 114
- My Blocks, 27
 - copying to another project, 55
 - creating, 53, 243
 - data wires and, 236
 - editing, 53, 239
 - input for, 236–238, 242
 - managing in project, 53–54
 - output from, 240, 242
 - sharing between projects, 243
 - troubleshooting missing, 351
 - uses for, 243
 - using, 53–54
 - using data wires with, 236

N

- naming programs and blocks, 352
- nesting Loop blocks, 51–52
- NETGEAR WNA1100 N150 Wi-Fi USB
 - Adapter, 358
- No Color tab, 191
- nonfriction pins, 105
 - flexible structures, 114
 - friction pins vs., 9–10
- Note, Sound block, 41
- Not mode, Logic Operations block, 233, 234
- Numeric array data wire, 215
- Numeric data wire, 214
- Numeric mode, Random block, 231
- Numeric variables, 246

O

- obstacles, avoiding, 90–91, 190–191
- 0-frame, 106
- On Brick programs, 25, 359
 - available blocks for, 362
 - blocks in, 360, 361
 - creating, 359
 - downloaded programs vs., 25
 - importing, 361, 363
 - opening, 361
 - running, 360
 - saving, 361
- On For Rotations mode, 190
- On/Off modes, Move Steering block, 45
- organizer for storing pieces, 5
- Or mode, Logic Operations block, 233
- output gear, 126
- output ports, 20
- Outside mode, 234

- P**
- Pan tool, 30
 - parallel beams
 - connecting, 112
 - securing, 111
 - pausing program, 49
 - perpendicular connections
 - axles, 132
 - gears, 130–131
 - pins, 9, 105
 - Play Type setting, Sound block, 40–41
 - Ports setting, 37
 - Port View tab, 354
 - power
 - consumption and regulated speed, 101
 - controlling motor speed, 37
 - Probability of True setting, 231
 - Programming Canvas, 27
 - programming software. *See* EV3 programming software
 - programs, 3. *See also* blocks (programming); On Brick programs
 - closing, 29
 - creating project for, 25
 - decompiling, 355
 - Demo* program, 22
 - downloading to the EV3, 25, 28
 - using Bluetooth, 356
 - using Wi-Fi, 358
 - finding on the EV3, 30
 - pausing, 49
 - placing blocks in, 26
 - projects vs., 29
 - renaming, 30
 - running
 - after downloading, 28
 - on the EV3, 22
 - manually, 28
 - troubleshooting, 352–353
 - saving, 29
 - testing changes in, 353
 - using My Blocks in, 53–54
 - projects
 - closing, 29
 - copying My Blocks to, 55
 - finding on the EV3, 30
 - managing My Blocks in, 53–54
 - one per robot, 30
 - opening, 29
 - programs vs., 29
 - properties for, 30
 - renaming, 30
 - sharing My Blocks between, 243
 - Proximity mode, 89
 - avoiding obstacles, 90–91
 - Pulse setting, 218
 - Pythagorean theorem, 130
- R**
- RAC3 TRUCK robot, 32–33
 - radius, of gears, 129
 - Radius setting, Display block, 43
 - Random block, 231
 - Range block, 234
 - Read mode, 247
 - Reflected Light Intensity mode, 75, 81
 - following line smoothly, 83
 - threshold value, 82
 - Refresh button, 354
 - regulated speed, 101
 - reinforcing structures, 107
 - remote control, 6
 - application, 22–23
 - batteries for, 4
 - controlling robot with, 6
 - program for Formula EV3 Race Car, 166–167
 - program for SNATCH3R, 300
 - using with Infrared Sensor, 92
 - Remote mode, Infrared Sensor, 92
 - renaming programs, 30
 - Reset mode, Timer block, 235
 - resource conflicts, 57
 - restarting the EV3, 355
 - robots. *See individual robots*
 - rotation
 - direction of gear trains, 126
 - reversing direction of, 135
 - speed of, 123
 - Rotation Sensor, 98
 - controlling wheel orientation, 163
 - Etch-A-Sketch* program coordinates, 254
 - keeping legs in sync, 332
 - motor position, 98
 - motor position, resetting, 99
 - purpose of, 62
 - regulated speed and, 101
 - resetting SNATCH3R grabber, 299
 - rotational speed, 99
 - calculating, 100
 - measuring in program, 100
 - Rotations mode, 37
 - Round block, 235
 - running programs
 - after downloading, 28
 - on the EV3, 22
 - manually, 28
 - troubleshooting, 352–353
 - Run Recent tab, 21
 - Run Selected command, 29
- S**
- saving programs, 29
 - SD_Card* folder, 356
 - Seconds mode, 37
 - Select tool, 30
 - Sensor blocks, 27, 217–218. *See also individual Sensor blocks*
 - Compare mode, 218
 - Measure mode, 217
 - sensors, 62
 - blocks allowing use of, 66
 - Brick Buttons, 97–98
 - building with, 119
 - built-in, 97
 - Change mode, 73
 - Color Sensor. *See* Color Sensor
 - Compare mode, 73
 - Infrared Sensor. *See* Infrared Sensor
 - input ports, 20
 - Loop block and, 68–69
 - measurement types, 66
 - Measure mode, 73
 - Port setting, 67
 - Rotation Sensor. *See* Rotation Sensor
 - Switch block and, 69
 - adding blocks to, 71
 - configuring, 70
 - Touch Sensor. *See* Touch Sensor
 - types of, 61
 - using multiple, 90–91
 - viewing values for, 66
 - Wait block and, 66–67
 - Sequence Wires, 28
 - multitasking via splitting, 56
 - Service Set Identifier (SSID), 358
 - Servo Motors. *See* motors
 - Settings tab, 21
 - Shapes mode, Display block, 42

- sharing My Blocks, 243
 - SK3TCHBOT robot, 200. *See also* data wires
 - building, 200–209
 - coordinates on screen, 254
 - parts list, 200
 - pencil controls
 - clearing screen, 257
 - moving without drawing, 255
 - pencil size, 257
 - using as eraser, 255
 - slash symbol (/), 332
 - smartphone, controlling robot with, 6
 - SNATCH3R robot, 263
 - Beacon Heading measurements and, 303
 - building, 266–298
 - grabber mechanism, 263–265
 - controlling, 299
 - troubleshooting, 301
 - lifting mechanism, 265
 - parts list, 266–267
 - remote control program, 300
 - searching for IR Beacon
 - building IR bug, 301–302
 - driving toward beacon, 307–308
 - lifting and moving beacon, 308
 - search algorithm, 303–306
 - sorting elements in organizer, 5
 - Sound block, 40
 - Duration setting, 41
 - Note or Tone for, 41
 - Play File mode, 40
 - Play Type setting, 40–41
 - signaling progress using, 353
 - volume, 40
 - speed
 - adjusting using data wires, 213
 - balancing with torque, 127
 - calculating for gears, 123
 - decreasing, using worm gear, 133
 - increasing and decreasing using gears, 123–124
 - regulated vs. unregulated, 101
 - spur gears, 128
 - SSID (Service Set Identifier), 358
 - stalled motors, 101
 - Start block, 27
 - multitasking using multiple, 56
 - State mode, 68
 - status light, 21, 44
 - steering
 - Formula EV3 Race Car
 - centering, 164–165
 - left and right, 164
 - resetting, 163
 - Move Steering block
 - modes for, 37
 - using, 35–36
 - Steering setting, 37
 - stickers on panels, 5
 - structure
 - aligning with LEGO unit grid, 108–109
 - flexible structures, 114–115
 - sub modes, 42–43
 - Switch block, 69
 - adding blocks to, 71
 - Change mode, 73
 - Compare mode, 73
 - comparing sensor values with
 - threshold, 82
 - configuring, 70
 - connecting data wires to block inside, 222–223
 - data wires and, 221
 - determining wheel orientation, 164
 - determining which button is pressed, 98
 - Measure - Color mode, 80
 - Numeric mode, 221
 - repeating, 72
 - using Random block with, 231
 - using with Beacon Heading mode, 94
 - using with Color Sensor, 77
 - swords, 119
 - synchronizing leg movements, 332–333
- ## T
- Tabbed View, 72
 - tablet, controlling robot with, 6
 - tank tread, 117
 - Technic line
 - EV3 set, 3
 - sorting elements, 5
 - testing
 - program changes, 353
 - using Display block, 42
 - test track, 77
 - Text block, 235
 - Text data wire, 214
 - Text mode, Display block, 43
 - Text variables, 246
 - thin elements, 114
 - threshold values, 82
 - Timer block, 218, 235
 - Tone, Sound block, 41
 - toolbar, programming software, 30
 - torque, 124–125
 - balancing with speed, 127
 - decreasing, 125
 - gears and, 127
 - increasing, 125, 126–127
 - Touch Sensor, 62
 - avoiding obstacles, 67
 - Change mode, 68, 73
 - combining with other sensors, 90–91
 - Compare mode, 68, 70, 73, 219
 - creating bumper using, 62–65
 - determining motor position, 172
 - LAVA R3X, 330
 - Measure mode, 73
 - State mode, 68
 - Switch block and, 69
 - Touch Sensor block, 218
 - TRACK3R robot, 4
 - troubleshooting
 - compilation errors
 - missing My Block, 351
 - missing variable definition, 352
 - programming block errors, 351–352
 - EV3 brick
 - connections, 354
 - Hardware Page, 354
 - memory management, 354–355
 - restarting, 355
 - updating firmware, 355
 - using USB connection, 355
 - grabber mechanism, SNATCH3R, 301
 - running programs, 352–353
 - turning opposite direction from
 - expected, 36
 - USB connection, 25
 - turning the EV3 on/off, 21
 - turning robot
 - accurate turns, 39
 - curved turns, 40
 - opposite direction from
 - expected, 36
 - twisting of axles, 135

U

- unit grid, 129
- Unregulated Motor block, 101
- unregulated speed, 101
- updating firmware, 25
- uploading file to computer, 355
- USB connection
 - when creating programs, 25
 - to external devices, 20
 - for loading programs, 3
 - for programming robot, 20
 - troubleshooting, 25, 355

V

- Variable block, 246–247
 - Constant block vs., 247
 - defining variables in, 247
 - using in program, 247
- variables, 245–246
 - calculating average using, 250
 - changing values, 249
 - defining, 246
 - incrementing values, 249
 - initializing start value, 249
 - troubleshooting missing definitions, 352
 - types for, 246
- View mode, 33
- volume, Sound block, 40

W

- Wait block, 49
 - Change mode, 73
 - Compare mode, 73
 - data wires and, 220
 - sensors and, 66–67
 - Touch Sensor mode, 66
 - using with Color Sensor, 77
- walking mechanism for ANTY, 172
- wheels
 - connecting to Large Motor, 117
 - controlling orientation, 163
- Wi-Fi, downloading programs using, 358
- wireless programming
 - Bluetooth
 - connecting with, 357–358
 - dongles, 357
 - downloading programs, 356
 - Wi-Fi, 358
- worm gears, 128, 133–134, 265

X

- XOR mode, Logic Operations block, 233

Z

- Zoom tool, 30