

## OTHER NUCLEO BOARDS

The following list contains other low-cost Nucleo boards. Many of these boards can be used for the programming examples. Some require minor changes in the examples.

For example, when the engineers at STMicroelectronics designed the NUCLEO-G070RB, they added two LEDs and changed the number of the user LED from LED2 to LED4. They also moved some bits around in the UART. The sample programs do work if you take these changes list below into account.

Boards in the same family (for example, F030R8, F070RB, F072RB, and F091RC) should work as the only difference between them is the amount of memory and some additional peripherals that we don't use.

I've tested the examples on all the boards I have. I've compiled examples for others, and they compile, but I've been unable to test. As I get access to additional boards, I'll be updating this list.

**NUCLEO-F030R8** Book was written for this.

**NUCLEO-F070RB** Should work with unmodified examples; untested.

**NUCLEO-F072RB** Should work with unmodified examples; untested.

**NUCLEO-F091RC** Tested with unmodified examples.

### NOTE

*Because memory size is different, some linker scripts look different.*

**NUCLEO-F103RB** Not recommended.

**NUCLEO-F302R8** Requires changing `GPIO_AF1_USART2` to `GPIO_AF7_USART2`; untested.

**NUCLEO-F303RE** Should be the same as F302R8; untested.

**NUCLEO-F334R8** Should be the same as F302R8; untested.

**NUCLEO-F401RE** Not recommended.

**NUCLEO-F410RB** Not recommended.

**NUCLEO-F411RE** Not recommended.

**NUCLEO-F446RE** Not recommended.

**NUCLEO-G070RB** Requires minor code changes. See <https://www.st.com/en/evaluation-tools/nucleo-g070rb.html>; tested.

**NUCLEO-G071RB** See <https://www.st.com/en/evaluation-tools/nucleo-g071rb.html> for possible changes; untested.

**NUCLEO-G0B1RE** See <https://www.st.com/en/evaluation-tools/nucleo-g0b1re.html> for possible changes; untested.

**NUCLEO-G431RB** Need to change GPIO\_AF1\_USART2 to GPIO\_AF7\_USART2; untested.

**NUCLEO-G474RE** Need to change GPIO\_AF1\_USART2 to GPIO\_AF7\_USART2; untested.

**NUCLEO-G491RE** Need to change GPIO\_AF1\_USART2 to GPIO\_AF7\_USART2; untested.

**NUCLEO-L010RB** Need to change GPIO\_AF1\_USART2 to GPIO\_AF4\_USART2; untested.

**NUCLEO-L053R8** Need to change GPIO\_AF1\_USART2 to GPIO\_AF4\_USART2; untested.

**NUCLEO-L073RZ** Need to change GPIO\_AF1\_USART2 to GPIO\_AF4\_USART2; untested.

**NUCLEO-L152RE** Not recommended.

**NUCLEO-L412RB-P** Change LED2 to LED4. Change GPIO\_AF1\_USART2 to GPIO\_AF3\_USART2. Should work; untested.

**NUCLEO-L433RC-P** Change LED2 to LED4. Change GPIO\_AF1\_USART2 to GPIO\_AF3\_USART2. Should work; untested.

**NUCLEO-L452RE** Change LED2 to LED4. Change GPIO\_AF1\_USART2 to GPIO\_AF3\_USART2. Should work; untested.

**NUCLEO-L452RE-P** Change LED2 to LED4. Change GPIO\_AF1\_USART2 to GPIO\_AF3\_USART2. Should work; untested.

**NUCLEO-L476RG** Change LED2 to LED4. Change GPIO\_AF1\_USART2 to GPIO\_AF3\_USART2. Should work; untested.